
Step 6: Preheating and Temperature Adjustment

Press the power button twice to start preheating. The screen will begin a countdown, based on different time periods chosen by the level, and the red indicator will flash during the preheating During preheating, press the power button once to pause heating,





Step 7: Ready To Use

Once preheating is completed, the green indicator light will stay on, indicating that the device is ready for use. The countdown on the screen will end and switch to a 1-hour timer, indicating active • Use the Up / Down buttons to fine-tune the temperature in

±20°C increments. • During use, press the power button once to pause operation, the indicator will then turn solid blue.



Pick up the hose and mouthpiece, then inhale to begin your session. The device provides up to 60 minutes of continuous use. During use, the indicator remains green.
When the session ends, a yellow indicator light will turn on as a reminder.



Step 9: After Your Session

Once you have finished your session, carefully unplug the device from the power source. Allow it to cool down completely before handling, cleaning, or storing it.





1x Bowl

Round Brush

1x Hookah Fork

1x Thick 1x Bowl Brush

CLEANING AND MAINTENANCE



To ensure optimal performance and long-term stability, please clean and maintain the device regularly.

• Ensure device is unplugged and completely cooled before cleaning. Use cup removal tool to carefully remove the used bowl, allow it to cool, and dispose of it safely.



• Gently wipe the ceramic bowl and surrounding areas with a soft,

absorbent cloth or paper towel. Clean the inner walls of the bowl using a damp, non-abrasive sponge and mild soap. Use the provided brush to thoroughly clean the inside of the ceramic bowl. Donl t forget to clean the bowl channel with the brush.



• Rinse the glass water tank, hose and mouthpiece under warm water with mild soap. Avoid using abrasive scrubbers on any parts to prevent damage.

DEVICE WARNING INDICATORS

Issue: A short circuit occurred in the device.



② Open Circuit or Sensor Error Issue: Open circuit or temperature sensor malfunction.

③ Over Temperature Issue: Temperature exceeds the device's safety limit.

Display: TOO HOT

4 Over Voltage or Under Voltage Issue: Voltage is above 18V or below 12V.



⑤ Heating Time-Up Issue: Heating time exceeded 60 minutes.

IMOTO USAGE PRECAUTIONS

The device is not waterproof. Do not wash or splash water on any part of the unit.

2. Do Not Open While In Use

Do not open the device cap during operation. 3. High Temperature Warning

The device cap and area around ceramic bowl become very hot during use. Do not touch these areas.

4. Ensure Proper Device Cap Closure After closing the device cap, ensure it is flush and fully aligned with the top of ceramic bowl cap.

5. Silicone Replacement Caution

When replacing the bottom silicone seal, be aware that residual liquid may be present. Use protective measures to avoid skin

6. Avoid Restarting During Use

Do not shut down and restart the device mid-session. Restarting while hot may lead to excessively high preheating temperatures, which can burn the material.

7. Avoid Extended Pauses During Use

To maintain optimal smoke density and flavor, avoid pausing inhalation for too long during a session. It is recommended not to exceed 6 minutes of idle time.

WARRANTY & SUPPORT

Enjoy exclusive warranty coverage, professional customer support, and comprehensive service assurance. Please visit our website or contact our support team at: support@imototech.com

Website: www.imototech.com/support/warranty

Or simply scan the QR code below.



G1 E-Hookah Kit **USER MANUAL**



IMOTO is a portable, charcoal-free e-hookah designed for smooth, modern hookah sessions-anytime, anywhere. Easy to use and powered by advanced technology, it delivers clean clouds, rich flavor, and hassle-free enjoyment.

WELCOME TO IMOTO

This manual will guide you through setup, usage, maintenance, and safety, so you can get the best performance from your IMOTO.



1x Mouthpiece & Hose Set

Bowl Caps



















3x Silicone Accessories

Round Brush

IMOTO G1 E-HOOKAH KIT PARTS



HOW TO OPERATE





Step 2: Load the Shisha Tobacco

Add 22-23g of shisha tobacco into the ceramic bowl and press it down firmly for optimal heating. For the best experience, check out our video guide at www.imototech.com. You'll also find more tips and info on our website.



Step 3: Install the Bowl

Place the clean ceramic bowl cap over the ceramic bowl, then insert the covered bowl into the G1 e-hookah head. Make sure it is securely positioned before closing the device cap.



Step 4: Power On

Connect the power cable. The blue indicator light will flash once to confirm a successful connection. Press the power button 5 times within 2 seconds to turn on the

The device will automatically shut-off after 20 minutes of inactivity when connected to power.



O Step 5: Set the Heating Level

Choose the right heating level based on your shisha tobacco type. Use the up / down buttons to switch between: Dark Leaf / Mix - 10 minutes heating duration. •Blonde Leaf - 12 minutes heating duration. Red Leaf - 14 minutes heating duration.



SHENZHEN EIGATE TECHNOLOGY CO., LTD. Floor 1-4, Building 3, No.14 Jian'an Road, Shajing Sub-district, Bao'an District, Shenzhen, Guangdong Province, China Tel: +86-755-8149-9783

Designed in California LK CEFC Responsibly made in China Manufactured by Eigate

